

NEXTORCH


Multi-tools series User Manual

Safety Consideration

As with most tools and pocket knives, several blades have sharp edges or points. Be extremely careful not to cut or pinch yourself with blades or handles when opening, closing or using your multi-tool. Please read the user manual carefully.

Maintenance

1. Clean your multi-tool after use, especially pay attention to the saline, grease, dirt and other, and ensure that no debris or dust clogging, and then dry it.
2. If necessary, lubricating oil should be dripped on the axis to ensure smooth operation.
3. Usually, grease or oil can be applied to prevent corrosion and rust.



- | | | | |
|----------------------|------------------|------------------------------------|---|
| 1 Needle-nose Pliers | 2 Regular Pliers | 3 Premium Replaceable Wire Cutters | 4 Premium Replaceable Hard-wire Cutters |
| 5 Thick-wire Cutters | 6 Saw | 7 Knife | 8 Phillips Screwdriver |
| 9 Line Cutter | 10 Wire stripper | 11 Can opener | 12 Bottle Opener |
| 13 Flat Screwdriver | 14 Glass Breaker | 15 Scissors | 16 Ruler |